

SURVEYING INSTRUCTION SHEET

Self surveying helps us to keep our prices as low as possible, however it is important that you follow these instructions carefully to ensure a correct sized cover is provided.

Please complete one survey sheet for each cover required. Please mark clearly to avoid errors and feel free to add any other notes that you may feel relevant.

1. Measure height of cover required. NOTE: You will need the cover to be ideally a minimum of 100mm above the height of the top of the radiator being covered.
2. Measure width of cover required. NOTE: You will need the cover to be ideally a minimum of 100mm longer than the radiator being covered including the valves (50mm each side).
3. Measure depth of cover required. NOTE: You will need the cover to be ideally a minimum of 70mm from the face of the radiator being covered.
4. If you require a pre-cut access hole for the valves please indicate the location on the survey sheet. Please give height measurements to the centre of the hole. NOTE: For ease of turning valves please try to ensure the hole centre is slightly higher than the top of the valve.
5. If you require skirting cut outs please indicate sizes and location on the survey sheet. NOTE: Skirting cut outs are always rectangular.

**IF IN DOUBT, PLEASE CALL, WE ARE
HAPPY TO HELP!**

Flexible radiator cover solutions



0800 246 5704



sales@polycoversdirect.co.uk



www.polycoversdirect.co.uk

Poly Covers Direct

Gallan Park
Watling Street
Cannock
WS11

Vat reg No. 304899281